Instructions

Tel: +44 (0) 1457 874 999 Fax: +44 (0) 1457 829 201

For more instructions & support material, please visit our website at:

http://www.cop-eu.com

WIRELESS AV TRANSMITTER USER MANUAL

MODEL: 15-2400VH, 15-1200VH1

1. Panel View







1. AUDIO: Input audio signal.
2. VIDEO: Input video signal.
3. 1 2 3 4: Channel Selection, transmitter select CH 1 and switch of the receiver select “1”, too.
4. DC+12V: Power input DC+12V.
5. POWER: Power indicator
6. ANT: Connect with antenna.

REMARK: When picture have the interference, adjust antenna or change the channel of transmitter.

2. Caution for Installation

2.1 Be careful, never let any water in this equipment.
2.2 If necessary, use a soft cloth moistened with alcohol to wipe off the dust.
2.3 Be extra careful not to shake the unit.
2.4 Avoid places where temperatures exceed 50 °C or more.
2.5 Avoid places where there is frequent vibrations or shocks.
2.6 When any abnormalities occur, make sure to unplug the unit and contact your local dealer.

3. Packing

3.1 Transmitter	×1
3.2 Antenna	×1
3.3 Bracket Holder	×1
3.4 Screw	×4
3.5 Plastic-Conical-Anchor	×4
3.6 AV Cable	×1
3.7 User manual	×1
3.8 Power Adaptor	×1

4. Specification

CHANNAL	CH1	CH2	CH3	CH4
FREQUENCY 15-2400VH	2413MHz	2432MHz	2451MHz	2470MHz
15-1200VH1	1080MHz	1120MHz	1160MHz	1200MHz
IMPEDANCE	50 Ohms Typical			
POWER	AC/ DC12V Adaptor			
CURRENT	530mA			
OUTPUT POWER	1W			
VIDEO INPUT	1 Vp-p Composite			
AUDIO INPUT	2 Vp-p Max.			
DIMENSIONS	L:47 ㎜	H:35 ㎜	D:61 ㎜	

VER 3